

model:BB-2000

# Vibration Alarm Clock


Thank you for your purchase! Please read these instructions carefully before use. Please keep this manual sheet for future reference.

## IMPORTANT/WARNING

- Do not expose this item to fire, water, or moisture.
- USB power adapter is not included.
- This is a vibrating product, so please be cautious about where you use it.
- Please do not use for purposes other than the intended use.

## What is inside


- Clock
- USB Type C cable
- Instruction Manual



- |                       |                            |
|-----------------------|----------------------------|
| A1 Time               | B1 - button                |
| A2 Alarm ON indicator | B2 + button                |
| A3 Charging icon      | B3 Snooze/Backlight button |
| A4 Battery life icon  | C1 Alarm function switch   |
| A5 Current time icon  | C2 Alarm ON/OFF switch     |
|                       | D1 USB port                |
|                       | D2 Reset button            |


## How to turn the clock on/off

You can turn the clock on/off by holding the -button (B1) for 3 seconds, and you will see "AM 8:00" displayed on the LCD.




## How to Charge the clock

1. Connect the included USB cable to the USB port (D1) on the clock and to a USB power adapter (sold separately).



2. Connect the USB power adapter to the outlet. The charging icon (A3) will be displayed on the LCD.



## Battery life icon

When the battery life icon (A4) shows only one bar, please recharge the clock as soon as possible. If the battery runs out, all settings will be reset.



## Backlight

When you press the Snooze/Backlight button (B3), the LCD screen will brighten for 5 seconds, allowing you to check the display even in low-light conditions.

## SNOOZE / LIGHT

## How to check the current time /Alarm time

- (a) When the alarm switch is off, the current time is always displayed on the LCD.
- (b) When the alarm switch is on, the alarm time is always displayed on the LCD.


In both (a) and (b) situations, pressing the - button (B1) will display the time that is not currently being shown for 3 seconds.

For example, in situation (b), pressing the - button will display the current time.

## How to set the current time

- ① Please confirm that the alarm switch (C2) is in the 'Off' (down) position.

Press and hold the Snooze/Backlight button (B3). "12" will start flashing. Press the - button (B1) or the + button (B2) to choose between 12Hr (12-hour time format) or 24Hr (24-hour time format).



- ② Press the Snooze/Backlight button.

The 'hour' part of the time display will start flashing. Press the - button or the + button to set the correct 'hour' for the time display.



- ③ Press the Snooze/Backlight button.

The 'minute' part of the time display will start flashing. Press the - button or the + button to set the correct 'minute' for the time display.

- ④ Press the Snooze/Backlight button to complete the setup.

- To set the "seconds" accurately, please use the correct time as a reference and complete the minute setting when the seconds are "00".
- If you don't press any buttons, the flashing will end in about 15 seconds, and the time display screen will return.
- During the setting, you can quickly change the numbers by long-pressing the -button or the +button.

## How to set alarm time

- ① Please confirm that the alarm switch (C2) is in the 'On' (up) position.

Press and hold the Snooze/Backlight button. The 'hour' part of the alarm time display will start flashing. Press the - button or the + button to set the desired 'hour' for the alarm time display.



- ② Press the Snooze/Backlight button.

The 'minute' part of the alarm time display will start flashing. Press the - button or the + button to set the desired 'minute' for the alarm time display.



- ③ Press the Snooze/Backlight button.

- When in the current time display, pressing the -button will display the alarm setting time for 3 seconds.
- If you don't press any buttons, the flashing will end in about 15 seconds, and the time display screen will return.
- During the setting, you can quickly change the numbers by long-pressing the -button or the +button.

## How to switch alarm type

- (1) Set the Alarm function switch (C1) to for vibration only.
- (2) Set the Alarm function switch (C1) to for vibration and sound
- (3) Set the Alarm function switch (C1) to for sound only.

## How to stop the alarm

To prevent accidentally stopping the alarm, you must set the alarm switch (C2) to 'Off' (down) for it to stop.

If you intend to use it the following day, be sure to set the alarm switch (C2) to 'On' (up).

Pressing the Snooze/Backlight button to stop the alarm will activate the snooze mode, and the snooze icon will flash on the LCD. Please refer to the 'Snooze Setting' section for more information.

## Snooze Setting

When the alarm is sounding, pressing the Snooze/Backlight button will temporarily silence the alarm, and it will resume after 5 minutes. The alarm icon will flash during the snooze mode.



If no button is pressed, it will automatically stop after 3 minutes and sound again at the same time the next day.

To cancel the snooze mode prematurely, set the alarm switch (C2) to 'Off' (down).

The snooze function can be repeated up to a maximum of 7 times.


## Alarm test function

When you long-press the + button, you can perform a trial of the set alarm.



## Others

You can attach a strap to the upper back of the clock for convenient portability. (Strap not included)



## Specifications

Time Precision: Average monthly difference of  $\pm 30$  seconds  
Operating Temperature Range: 0°C to 40°C

Alarm Features: Approximately 3 minutes auto-stop, snooze function, vibration alarm, sound alarm (gradually increases in volume).

snooze can be repeated up to 7 times

Display Contents: Time (12/24-hour format), alarm time, battery charge level

Alarm Sound: Electronic sound (approximately 3 minutes)  
Input: 5V/1A (It can be charged with a computer, but make sure to check the specifications before charging)

Material: ABS

Charging Time: Approximately 70 minutes (from 0% to full charge)

Consecutive Usage Days: Approximately 300 days without recharging (when using the vibration alarm for 30 seconds per day from a full charge)

USB Adapter: A USB adapter is not included.

Please use one that you have or purchase one separately.  
Adapter Power: Adapters with 5W or more can be used, but it won't affect the charging speed.

Reset on Battery Depletion: If the battery runs out, all settings will be reset.

Product Changes: Specifications and appearance of this product may be subject to change without prior notice for product improvements.

Made in China

